



NOTES:

1) TRACER WIRE SHOWN AWAY FROM PIPE FOR CLARITY. WIRES SHALL BE INSTALLED ON THE BOTTOM SIDE OF THE PIPE BELOW THE SPRING LINE. THE WIRE SHALL BE FASTENED TO THE PIPE WITH TAPE OR PLASTIC TIES AT 5' INTERVALS.

DATE REVISED  
03/15/17

# SANITARY SEWER TRACER WIRE SYSTEM DETAILS

PLATE NO.  
5-07